



CORDLESS CELLULAR SHADE




PACKAGE CONTENTS




HARDWARE CONTENTS

AA




Mounting Bracket
18 in. - 42 in. = x 2
- 72 in. = x 3
45.72 cm - 106.68 cm = x 2
- 182.88 cm = x 3

BB



Handle
= x 1

CC



Wood Screw
18 in. - 42 in. = x 4
- 72 in. = x 6
45.72 cm - 106.68 cm = x 4
- 182.88 cm = x 6

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

PREPARATION

Before beginning installation of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

Estimated Assembly Time: 30 minutes


Tools Required for Assembly (not included): Measuring tape, drill with 3/32in. bit, screwdriver and pencil.

Bracket Location and Installation:


The shade may be installed either inside or outside the window frame. A mounting bracket should be positioned on each end of the headrail. Wider shades that require 3 or more brackets should be spaced evenly between the two outermost brackets. Always position the brackets such that there is no interference with cords and mechanisms inside the headrail. The procedure outlined below will assure proper bracket placement.

ASSEMBLY INSTRUCTIONS


1a. For outside mounting, clip the mounting bracket (AA) onto the headrail of shade (A). Hold shade (A) level at the height desired and center it over the window opening. Mark the exact location of each mounting bracket (AA) with a pencil. Remove the mounting brackets (AA) from the headrail of shade (A). Predrill the screw holes and then securing bracket (AA) to the wall or window molding with wood screws (CC).




1b. For inside mounting, clip the mounting brackets (AA) onto the headrail of shade (A). Hold shade (A) in place and make pencil mark at the rear of each mounting bracket (AA). Remove the mounting brackets (AA) from the headrail. Predrill the screw holes and then secure the mounting bracket (AA) to the wall or window molding with wood screws (CC).



2. Lift the headrail of shade (A) into position such that the inner front edge of the headrail slides into the slot at the front of each mounting bracket (AA). Push the headrail upward until the flexible tab at the bottom of each mounting bracket (AA) snaps onto the back of the headrail. Check carefully to assure each mounting bracket (AA) is properly snapped into place.




3. Attach the handle (BB) to the center of the bottom rail of shade (A). Check carefully to assure that the handle (B) is properly snapped into place.



To remove brackets from headrail

Use flathead screwdriver and insert into mounting bracket tab (AA). Push back tab with screw-driver to release bracket (AA) from headrail.



CARE AND MAINTENANCE

The vinyl headrail and bottom rail can be wiped clean with a damp sponge. To clean the shade fabric, use a feather duster or vacuum lightly using the soft brush attachment

ONE-YEAR LIMITED WARRANTY

For a period of one (1) year from the date of purchase, the manufacturer will replace this window covering with one of equal or superior value, if this window covering is found to be defective in material or workmanship. To obtain warranty service contact our customer service department. This warranty does not cover damage of defects caused by or resulting from improper maintenance, negligent or improper use, abuse, misuse, neglect, accidents, act of God, alteration, commercial use, installation, removal or reinstallation.

This warranty is restricted to normal consumer use within the United States and Canada.

MANUFACTURER WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

WARNING

STRANGULATION HAZARD - Young children can be strangled by cords. Immediately remove this product if a cord longer than 22 cm or a loop exceeding 44 cm around becomes accessible.